

# Frequently Asked Questions

- What thickness of concrete do you recommend?
  - We recommend 6-12 inches reinforced concrete that has cured for at least 28 days.
- What is the recommended PSI for the concrete?
  - We recommend a psi of 3,000
- Does the lift come with anchor bolts and how many?
  - Yes the lift comes with Anchor Bolts. There will be 16 in total
- What are the specs of the Anchor Bolts?
  - The Anchor bolts are 3/4 diameter 6" long anchors bolts
- What are the torque specifications?
  - We recommend 90 foot-pounds, never less than 80 or more than 110 foot-pounds.
- What is the recommended breaker for this lift?
  - We recommend a 30A breaker
- Does this lift come with a plug?
  - The lift does not come with a plug, you will need to get a 220v-250v, 30A plug
- How do I hook up the electrical?
  - Yellow/green is ground, the other 2 are hot
- How long does the power cord reach?
  - The cord is 11 feet
- Is there a way to change the speed of the lift?
  - Yes, with the oil flow valve, you can tighten (clockwise) which will slow the lift, or loosen (counter clockwise) which will speed up the lift.
- How do I lower the lift that is stuck in the air?
  - Release the safety locks and then release pressure of the hydraulic system.